



5602 Greenbay Road
Kenosha, WI. 53144
Phone: (262)654-3222
Email: jumpnjaxinc@hotmail.com
Website: JumpNJax.com

Snow Cone Machine Operating Instructions

Instructions and Rules

1. **Be sure equipment is connected to a properly grounded 120 Volt power supply with 15 AMP Circuit.**
2. **BE CAUTIOUS and keep all children away from the sharp blades in the ice horn. IT WILL CAUSE SERIOUS INJURY.**
3. Turn the power switch to the ON position.
4. Fill the ice horn with ice.
5. Press and hold the Motor switch to activate the blades and begin shaving the ice.
6. While holding the Motor switch down, apply a steady downward pressure to the ice pusher
7. Release the Motor switch when finished.
8. Repeat steps 3 through 6 for additional batches.

CLEANING

CAUTION THE BLADES ARE SHARP AND CAN CAUSE SERIOUS INJURY.

1. Remove all ice from the horn and storage compartment.
2. Operate the motor for several minutes to remove any water collection.
3. Turn off the POWER switch.
4. Unplug the power cord from the electrical outlet.
5. Using a clean cloth, wipe down the following items:
 - ❖ The inner surface of the ice horn,
 - ❖ The outside surface of the ice horn casting.
 - ❖ The Ice Pusher
 - ❖ All interior and exterior surfaces.

To clean the water tray:

- ❖ Tilt the tray to drain the water trapped in the drain cavity.
- ❖ Slip the drain hose off of the nipple fitting.
- ❖ Lift the tray out of the cabinet.
- ❖ Clean tray and area below tray with clean cloth.
- ❖ **FDA approved cleaners may be used when required for sanitation. DO NOT use ammonia based cleaners on door or side panels.**

EXTREME CAUTION!! BLADES ARE SHARP AND OPERATE AT HIGH SPEEDS!

Please be careful to keep all body parts and any objects such as ice picks or scoops away from the ice horn while the machine is on.

The renter takes full responsibility for the Snow Cone Machine's safe use and for following all of the instructions for safe uses that are not limited to or all inclusive of the rules stated above. Jump N' Jax Inc. is not liable for any misuse of the product or injury that may result from it's misuse or blatant dis-regard and not following the cautions stated. In the event the unit is damaged or vandalized renter is responsible for the repair or replacement of rented unit not to exceed \$1000 dollars.

Thank You, YOUR FUN IS OUR BUSINESS

I have read and understand this agreement,

Signature: _____ Date: _____